## PORIGINAL BRASS INTERNALS





Original Brass RAPIDJACK® Check Valves

| PART#   | SIZE | LH/RH | DESCRIPTION            |
|---------|------|-------|------------------------|
| H56A37A | 4"   | LH    | RAPIDJACK® Check Valve |
| H56A37B | 4"   | RH    | RAPIDJACK® Check Valve |
| H56A37C | 6"   | LH    | RAPIDJACK® Check Valve |
| H56A37D | 6"   | RH    | RAPIDJACK® Check Valve |

## **RAPIDJACK® BUYING OPTIONS**

**OPTION 1: PART** 

The **RAPIDJACK**<sup>®</sup> can be purchased as a stand-alone part that inserts into new piping layouts or can replace valves measuring 5" lay length for 4" piping or 5.5" lay length for 6" piping.

REQUIREMENT: MUST HAVE SPACE FOR A 5" LAY LENGTH FOR 4" PIPING OR 5.5" LAY LENGTH FOR 6" PIPING.

**OPTION 2: PIPING SKID** 

Many Smith & Loveless® pump stations require a new piping skid to insert the **RAPIDJACK®** because the lay length of the **RAPIDJACK®** is larger than a standard wafer check valve.

Smith & Loveless® can review each pump station's piping layout and determine what piping modifications are required.